


KENWOOD

MultiPro Express Weigh+ TYPE FDM71

Instructions








English








2 - 15





عربي

٣٠ - ١٦







15/16**18-19-20****22****23****17****21****24**

25**26****27****27A**


28





28+27



29



30



Safety

- Read these instructions carefully and retain for future reference.
- Remove all packaging and any labels.
- If the plug or cord is damaged it must, for safety reasons, be replaced by Kenwood or an authorised Kenwood repairer in order to avoid a hazard.
- **DO NOT touch the sharp blades.** The blades and discs are very sharp, handle with care. **Always hold by the finger grip at the top, away from the cutting edge, when handling the sharp cutting blades, emptying the bowl and during cleaning.**
- **DO NOT process hot ingredients.**
- **Be careful if hot liquid is poured into the food processor or blender as it can be ejected out of the appliance due to sudden steaming.**
- Never leave the appliance unattended when it is operating.
- Do not exceed the maximum capacities stated in the recommended usage chart.
- **Do not operate your appliance for longer than the times specified below without a rest period. Processing continuously for longer periods can damage your appliance.**

| Function/Attachment | Maximum Operation Time | Rest Period Between Operations |
|---|------------------------|--|
| Blender/Blend-Xtract 2GO | 60 secs | |
| Heavy mixtures in the bowl (e.g. Dough) | 60 secs | |
| Mini Chopper/Mill | 30 secs | |
| Grinding Mill | 60 secs | Unplug the appliance and allow to cool down for 15 minutes |

- Do not lift or carry the processor by the handle - or the handle may break resulting in injury.
- Always remove the knife blade before pouring contents from the bowl.
- Keep hands and utensils out of the processor bowl and blender goblet whilst connected to the power supply. If food needs to be pushed down use a suitable utensil such as a spatula.
- Always switch off the appliance and disconnect from the supply if it is left unattended and before assembling, disassembling or cleaning.
- Never use your fingers to push food down the feed tube. Always use the pusher supplied.
- **Never fit the blade assembly to the power unit without the glass goblet/bottle or mill jar/lid fitted.**
- CAUTION: Before removing the lid from the bowl, blender or mill from the power unit:

- switch off;
- wait until the attachment/blades have completely stopped;
- be careful not to unscrew the glass goblet/bottle or mill jar/lid from the blade assembly.
- Do not use the lid to operate the processor, always use the on/off speed control.
- **This appliance will be damaged and may cause injury if the interlock mechanism is subjected to excessive force.**
- Never use an unauthorised attachment.
- Never use a damaged appliance. Get it checked or repaired: see 'Service and Customer Care'.
- Never let the power unit, cord or plug get wet.
- Do not let excess cord hang over the edge of a table or worktop or touch hot surfaces.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Only use the appliance for its intended domestic use. Kenwood will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.
- Misuse of your processor, blender or mill can result in injury.
- The maximum rating is based on the mini chopper/mill attachment that draws the greatest load. Other attachments may draw less power.

Blender/Blend-Xtract 2GO

-  **DO NOT process hot ingredients.**
- **SCALD RISK:** Hot ingredients must be allowed to cool to room temperature before placing in the goblet/bottle or before blending.
- Always take care when handling the blade assembly and avoid touching the cutting edge of the blades when cleaning.
- Only operate the blender with the lid in place.
- Never run the blender empty.
- Smoothie recipes - never blend frozen ingredients that have formed a solid mass during freezing, break it up before adding to the goblet/bottle.

Blend-Xtract 2GO

- Only use the bottle with the blade assembly supplied.
- Never drink any hot liquids from the bottle.
- When drinking through the lid, take care that the drink is smooth. Some experimentation may be necessary to achieve

the desired result, particularly when processing firm or unripened foods as you may find that some ingredients remain unprocessed.

- Do not blend frozen ingredients or ice cubes without liquid.
- Never blend dry ingredients (e.g. spices, nuts) or run the Blender empty.

Glass Thermoresist Blender only

IMPORTANT: HOT BLENDING INSTRUCTIONS

To minimise the possibility of scalding when blending hot ingredients keep hands and other exposed skin away from the lid to prevent possible burns.

The following precautions must be observed:

- **CAUTION: Blending very hot ingredients may result in hot liquid and steam being forced suddenly past the lid or filler cap.**
- **We recommend that hot ingredients are allowed to cool before blending.**
- **NEVER** exceed the hot liquid marking  on the goblet if processing hot ingredients, such as soups.
- **ALWAYS** commence blending at a low speed and gradually increase the speed. **NEVER** blend hot liquids by using the Pulse setting.
- Liquids which tend to foam such as milk, should be limited to a maximum capacity of 1000mls/4 cups.
- Take care when handling the blender as the goblet and its contents will be very hot.
- Take particular care when removing the lid. The lid is designed to be a tight fit to prevent leakage. If necessary protect your hands with a cloth or oven gloves when handling.
- Ensure the goblet is securely attached to the base and when removing from the appliance, guide the base and ensure it is removed together with the goblet.
- Ensure that the lid and filler cap are securely in place before **every** blending operation.
- Always ensure that the vents in the filler cap are clear before **every** blending operation.
- When fitting the lid to the goblet always ensure that the lid and goblet rim are clean and dry to ensure a good seal and prevent spillage.

Mill Attachments

- Never fit the blade assembly to the power unit without the jar/lid fitted.
- Never unscrew the jar/lid while the mill is fitted to your appliance.
- Do not touch the sharp blades - Keep the blade assembly away from children.
- Never remove the mill until the blades have completely stopped.

- The appliance will not work if the mill is incorrectly fitted.
- Do not process hot ingredients in the mill allow to cool down to room temperature before processing.

Mini Chopper/Mill

- The processing of spices is not recommended as they may damage the plastic parts.

Grinding Mill

- Do not process dried turmeric root as it is too hard and may damage the blades.

Juice extractor

- Do not use the juicer if the filter, juicer lid or bowl are damaged or has visible cracks.
- The cutting blades on the base of the filter drum are very sharp, take care when handling and cleaning the drum.
- Only use the pusher supplied. Never put your fingers in the feed tube. Unplug before unblocking the feed tube.
- Before removing the lid, switch off and wait for the filter to stop.

Express Dice/Express Serve Attachment and Discs

- The cutting grid and discs are very sharp; handle with care when fitting, removing and cleaning. **Always hold by the finger grip away from the cutting edge when handling the sharp cutting blades, emptying the bowl and during cleaning.**
- Never use your fingers to push food down the feed tube. Only use the pusher supplied.
- Do not use excessive force to push food down the feed tube - you could damage your attachment.
- Before removing the lid, switch off and wait until the disc has completely stopped.
- Do not pour hot liquids down the feed tube.

Express Serve

- Avoid contact with moving parts. Keep fingers out of the food outlet opening.
- Do not operate when using the Dicer or Discs without the slinger plate fitted. **If the slinger plate is not fitted food will clog under the plate and not exit the food outlet, resulting in damage to your attachment.**
- The citrus juicer is not designed to be used with the Express Serve. Always use the citrus juicer with the main bowl.

Cleaning

- Wipe the power unit and whisk drive head with a damp cloth, then dry. Ensure that the interlock area is clear of food debris.

- Do not immerse the power unit, whisk drive head or blade assemblies in water.
- The bowl, lid, pusher and all attachments/tools apart from the blade assemblies and whisk drive head are suitable for both handwashing and dishwashing.
- The blade assemblies should be brushed clean and rinsed under running water.
- Blender with fixed blades - Do not dishwash or immerse the blender base in water. Fill with warm water, fit the lid, then switch on for 20-30 seconds. Empty, then rinse. If it is still dirty use a brush. Wipe, then leave to air-dry.

Important – Plug and Fuse Information

Before plugging in

- Make sure your electricity supply is the same as the one shown on the underside of your appliance.
 - The wires in the cord are coloured as follows:
Blue = Neutral
Brown = Live
 - If the plug supplied with your appliance has a fuse fitted and the fuse fails it must be replaced with one of the same rating.
 - If the plug or cord requires replacing a new cord set should be fitted by an Authorised Kenwood Repairer.
- Note:**
- For non-rewireable plugs the fuse cover MUST be refitted when replacing the fuse. If the fuse cover is lost then the plug must not be used until a replacement can be obtained. The correct fuse cover is identified by colour and a replacement may be obtained from your Kenwood Authorised Repairer (see Service).
 - If a non-rewireable plug is cut off it must be DESTROYED IMMEDIATELY. An electric shock hazard may arise if an unwanted non-rewireable plug is inadvertently inserted into a socket outlet.
 - This appliance conforms to EC Regulation 1935/2004 on materials and articles intended to come into contact with food.

Before using for the first time

- 1 Remove the plastic blade covers from the knife blade. **Take care the blades are very sharp.** These covers should be discarded as they are to protect the blade during manufacture and transit only.
- 2 Wash the parts see 'care and cleaning'.

Key

Processor - Express Prep

- ① Pushers
- ② Feed tube
- ③ Lid
- ④ Bowl
- ⑤ Detachable drive shaft
- ⑥ Power unit
- ⑦ Speed/pulse control
- ⑧ Safety interlocks
- ⑨ Cord storage (at back)

Weighing Function

- ⑩ Kg/lb button
- ⑪ On/zero button
- ⑫ Display screen
- ⑬ Weighing tray

14A Glass Thermoresist™ Blender (if supplied)

- a Filler cap
- b Lid
- c Glass goblet
- d Sealing ring
- e Blade unit
- f Base
- g Filler cap vents

14B Plastic Blender (if supplied)

- a Goblet with fixed blade
- b Lid with drip feed

A Standard Attachments

- (15) Knife blade
- (16) Dough tool
- (17) Dual whisk
- (18) 4mm slicing/grating disc
- (19) 2mm slicing/grating disc

Not all of the attachments listed below may be included with your food processor. Attachments are dependent upon the model variant. Visit www.kenwoodworld.com for information on how to buy an attachment not included in pack.

B Optional Attachments

- (20) Extra fine grating disc (if supplied)
- (21) Citrus juicer (if supplied)
- (22) Glass mini chopper/mill (if supplied)
- (23) Plastic mini chopper/mill (if supplied)
- (24) Grinding mill (if supplied)
- (25) Blend-Xtract 2GO (if supplied)
- (26) Juice extractor (if supplied)
- (27) Express Dice (if supplied)
- (28) Express Serve (if supplied)
- (29) Storage bag (if supplied)
- (30) Spatula

To Use Your Food Processor

Illustrations ① - ③

- 1 Fit the detachable drive shaft onto the power unit.
- 2 Then fit the bowl to the power unit and turn clockwise until it locks into position.
- 3 Fit an attachment over the bowl drive shaft.
- Always fit the bowl and attachment onto the processor before adding ingredients.
- 4 Fit the lid - ensuring the top of the drive shaft/tool locates into the centre of the lid.
- **Do not use the lid to operate the processor, always use the on/off speed control.**
- 5 Plug in, switch on and select a speed. (Refer to the recommended usage chart).
- **The processor will not operate if the bowl or lid are not fitted correctly into the interlock. Check that the feed tube and bowl handle are situated to the right front hand corner.**
- Use the pulse (**P**) for short bursts. The pulse will operate for as long as the control is held in position.
- 6 Reverse the above procedure to remove the lid, attachments and bowl.
- **Always switch off and unplug before removing the lid.**

Important

- Your processor is not suitable for crushing or grinding coffee beans, or converting granulated sugar to caster sugar.

- When adding almond essence or flavouring to mixtures avoid contact with the plastic as this may result in permanent marking.

Weighing Function

Illustration ④

Your food processor is fitted with a built in weighing function to allow ingredients to be weighed straight into the bowl or blender goblet.

- The Maximum weighing capacity is 3kg.

To Use The Weighing Function

- 1 Always fit the bowl, detachable drive shaft and attachment or blender goblet onto the power unit before adding ingredients.
- 2 Plug in - the display screen will remain blank.
- 3 Press the ON/ZERO button once and the display screen will light up.
- 4 Press the (kg/lb) button to select either grams or ounces. The display will default to kg/g when first switched on.
- The unit weighs in 1g increments and teaspoon/tablespoon measures are recommended for weighing small quantities.
- To zero press the ON/ZERO button once.
- 5 Weigh the required ingredients straight into the bowl or goblet.
- 6 After all the ingredients are weighed fit the lid and select a speed to operate the processor.
- The weight of any additional ingredients added down the feed tube whilst the processor is running will not be shown on the display screen.
- The display screen can be turned off manually by pressing and holding down the ON/ZERO button for a few seconds.

Refer to the troubleshooting guide if you experience any problems with operating the weighing function.

Weighing Tray

A removable weighing tray is supplied for weighing ingredients without the bowl or blender.

To use, place the tray on top of the power unit and turn clockwise to secure. Then follow steps 2 to 4 under 'To Use The Weighing Function'.

To remove, rotate the tray anti-clockwise and lift off.

Using The Attachments

Refer to the usage chart, illustrations and relevant section for each attachment.

14A Glass Blender (if supplied)

To Use Your Blender

Illustrations 14A

- 1 Fit the sealing ring into the blade unit - ensuring the seal is located correctly in the grooved area.
- **Leaking will occur if the seal is damaged or incorrectly fitted.**
- 2 Screw the goblet onto the blade assembly. Refer to the graphics on the underside of the blade unit as follows:
 - - Unlocked position
 - - Locked position
- 3 Put your ingredients into the goblet.
- 4 Fit the lid to the goblet and push down to secure. Fit the filler cap.
- 5 Place the blender onto the power unit, align the ■ on the blender with the ■ on the power unit and turn clockwise to lock ■.
- **The appliance will not operate if the blender is incorrectly fitted to the interlock.**

14B Plastic Blender (if supplied)

Illustrations 14B

- 1 To assemble and use - refer to the Blender illustrations and the Recommended Usage Chart.
- 2 Put your ingredients into the goblet.
- 3 Fit the lid onto the goblet and turn clockwise until it clicks.
- 4 Fit the blender to the power unit and turn clockwise to lock in position.
- **The appliance will not operate if the blender is incorrectly fitted to the interlock.**

Hints and Tips

- When making mayonnaise, put all the ingredients, except the oil, into the blender. With the appliance running:
 - Glass Blender** - remove the filler cap and pour the oil through the hole in the lid.
 - Plastic blender** - pour the oil through the drip feed hole in the lid.
- Thick mixtures, e.g. pâtés and dips, may need scraping down. If the mixture is difficult to process, add more liquid.
- The processing of spices is not recommended as they may damage the plastic parts.

15 Knife Blade

Follow the instructions under 'To Use Your Food Processor'.

Hints and Tips

- For coarser textures use the pulse control.
- Cut food such as meat, bread, vegetables into cubes approximately 2cm.
- Biscuits should be broken into pieces and added down the feed tube whilst the appliance is running.
- Take care not to over-process.
- When making pastry use fat straight from the fridge cut into 2cm cubes.
- For best results when processing sticky fruit/ingredients such as dates, use 'Pulse' first to break down the ingredients and then continue processing on maximum speed.

16 Dough Tool

Use for yeasted dough mixes.

Follow the instructions under 'To Use Your Food Processor'.

Hints and Tips

- Do not process for longer than 60 seconds.
- Place the dry ingredients in the bowl and add the liquid down the feed tube whilst the appliance is running. Process until a smooth elastic ball of dough is formed.
- Re-knead by hand only. Re-kneading in the bowl is not recommended as it may cause the processor to become unstable.

17 Dual Whisk

- 1 Fit the bowl onto the power unit, add the detachable drive shaft.
- 2 Push each beater into the drive head.
- 3 Fit the whisk by carefully turning until it drops over the drive shaft.
- 4 Add the ingredients.
- 5 Fit the lid - ensuring the end of the shaft locates into the centre of the lid.
- 6 Switch on.

important

 **The whisk is not suitable for making all in one cake mixes as these mixes are too heavy and will damage it. Always use the knife blade.**

Hints and Tips

- Best results are obtained when the eggs are at room temperature.
- Ensure the bowl and whisks are clean and free from grease before whisking.

creaming fat and sugar

- For best results fat should be allowed to soften at room temperature (20°C) before creaming. **DO NOT use fat straight from the fridge as this will damage the whisk.**
- Heavier ingredients such as flour and dried fruit should be folded in by hand.
- Do not exceed the maximum capacity or processing time stated in the recommended speed chart.

18 - 19 - 20 Discs

- 1 Fit the drive shaft and bowl onto the power unit.
- 2 Holding by the centre grip, place the disc onto the drive shaft with the appropriate side uppermost.
- 3 Fit the lid.
- 4 Put the food in the feed tube. Choose which size feed tube you want to use.
To use the small feed tube - first put the large pusher inside the feed tube. Use for individual thin ingredients.
- Do not use the small pusher without the larger pusher fitted, otherwise you may damage the bottom of the pusher.**
- To use the large feed tube** - use both pushers together.
- 5 Switch on and push down evenly with the pusher ① - **never put your fingers in the feed tube.**

Hints and Tips

- Use fresh ingredients
- Do not cut food too small. Fill the width of the feed tube fairly full. This prevents the food from slipping sideways during processing.
- When slicing or grating: food placed upright comes out shorter than food placed horizontally.
- There will always be a small amount of waste on the disc or in the bowl after processing.

21 Citrus Juicer (if supplied)

- a Cone
- b Sieve

To use the citrus juicer

- 1 Fit the drive shaft and bowl onto the power unit.
- 2 Fit the sieve into the bowl - ensuring the sieve handle is locked into position directly over the bowl handle.
- 3 Place the cone over the drive shaft turning until it drops all the way down.
- 4 Cut the fruit in half. Then switch on and press the fruit onto the cone.
- The citrus juicer will not operate if the sieve is not locked correctly.**

Hints and Tips

- For best results store and juice the fruit at room temperature and hand roll on a worktop before juicing.
- To help with juice extraction move the fruit from side to side when juicing.
- When juicing large quantities, empty the sieve regularly to prevent the build up of pulp and seeds.

22 - 23 Mini Chopper/Mill (if supplied)

- a Jar
- b Sealing ring
- c Blade assembly

- 1 Put the ingredients into the jar.
- 2 Fit the sealing ring into the blade assembly.
- 3 Turn the blade assembly upside down. Lower it into the jar, blades down.
- 4 Screw the blade assembly onto the jar until finger tight. Refer to the graphics on the underside of the blade assembly as follows:
 - Unlocked position
 - Locked position
- 5 Place the mill onto the power unit and turn clockwise to lock in position
- 6 Select Maximum speed or use the pulse (P).

Hints and Tips

- Baby food/purée - allow cooked food to cool down to room temperature before processing in the mill.
- For best results the main bowl is recommended when chopping herbs.

24 Grinding Mill (if supplied)

- a Mill lid
- b Grinding mill blade assembly

- 1 Place your ingredients into the blade assembly.
- 2 Fit the lid and turn clockwise to lock.
- 3 Place the mill onto the power unit and turn clockwise to lock.
- 4 Select maximum speed or use the pulse (P).

Hints and Tips

- For optimum performance when processing spices do not process more than 50g at a time.
- Whole spices retain their flavour for a much longer time than ground spices so it is best to grind a small quantity fresh at a time to retain the flavour.
- To release the maximum flavour and essential oils whole spices are best roasted prior to milling.

- Do not process dried turmeric root in the mill as it is too hard and may damage the blades.
- Cut ginger and coconut into small pieces before processing.
- For best results the main bowl is recommended when chopping herbs.

25 Blend-Xtract 2GO (if supplied)

- Dispensing lid
- Bottle
- Sealing ring
- Blade assembly

- 1 Add ingredients to the bottle up to the 400ml level mark.
- For best blending performance always add ice/frozen ingredients to the bottle first.
- When adding frozen ingredients (i.e. frozen fruit, yoghurt, ice cream or ice) do not blend more than 60g or 3 ice cubes.
- Do not blend frozen ingredients without liquid.
- 2 Fit the sealing ring to the blade unit, ensuring the seal is located correctly in the grooved area.
- Leaking will occur if the seal is damaged or incorrectly fitted.
- 3 Hold the underside of the blade unit and lower it onto the bottle, blades down.
- 4 Screw the blade holder onto the bottle - turn clockwise to lock.
- Shake to disperse the ingredients.
- Place the blender onto the power unit and turn clockwise to lock.
- 5 Select maximum speed. Allow the ingredients to blend until smooth.
- Once your drink has reached the desired consistency, you can use the pulse (P) to ensure all ingredients are thoroughly blended.

Hints and Tips

- Note that when the bottle is filled to max capacity (400ml), this is approximately two servings.
- If you do not intend to consume your drink immediately, keep it refrigerated.
- Ensure your drink is thin enough to be able to drink from the dispensing lid. To make a thinner drink add more liquid.
- After blending, some drinks may not be completely smooth due to seeds or the fibrous nature of ingredients.
- Some drinks may separate on standing, therefore it is best to drink them straight away. Separated drinks should be stirred before drinking.
- When the dispensing lid is fitted always keep the bottle upright.

Using the drinking lid

- 1 Fit and lock the lid by turning clockwise.
- 2 When you want to drink, simply flip open the lid cover. The drink can be consumed straight from the bottle.

26 Juice Extractor (if supplied)

- Pusher
- Juicer lid
- Pulp remover
- Filter drum
- Bowl
- Juicing spout

To use the juice extractor

- 1 Fit the juicer bowl to the power unit, turn clockwise until it locks - the spout should be situated to the left side when the bowl is fitted correctly.
- 2 Place the pulp remover into the filter drum - ensuring the tabs locate with the slots in the bottom of the drum.
- 3 Fit the filter drum
- 4 Fit the attachment lid - turn clockwise until it locks. **Your juicer will not operate if the bowl or lid are not fitted correctly into the interlock .**
- 5 Place a suitable glass or jug under the juice outlet.
- 6 Cut the food to fit the feed tube.
- 7 Switch on and push down evenly with the pusher - never put your fingers in the feed tube. Process fully before adding more.
- After adding the last piece, let the juicer run for a further 30 seconds to extract all the juice from the filter drum.

important

- If the juicer starts to vibrate, switch off and empty the pulp from the drum. The juicer vibrates if the pulp becomes unevenly distributed.
- Some very hard foods may make your juicer slow down or stop. If this happens switch off and unblock the filter.
- Switch off and clear the pulp collector regularly during use.

Hints and Tips

- Before processing remove stones and pips (eg pepper, melon, plum) and tough skins (e.g. melon, pineapple). You do not need to peel or core apples and pears.
- Use firm, fresh fruit and vegetables.

27 Express Dice (if supplied)

- a Dicing disc
- b Dicing grid
- c Dicing pusher

Important:

- The dicing disc is designed only to be used with the dicing attachment.
- The dicing pusher should only be used with the dicing grid. Using it without the dicing grid fitted will result in damage to the bottom of the pusher.

To use the Express Dice

- 1 Fit the drive shaft and bowl onto the power unit.
- 2 Add the dicing disc and fit the lid.
- 3 Fit the dicing grid into the feed tube.
- 4 Switch on and use the dicing pusher to process food items through the dicing grid.

Hints and Tips

- To assist with processing place both hands on top of the pusher and press down firmly.
- For best results, use fresh fruit and vegetables.
- To prevent the food from jamming do not pack the food tightly in the feed tube – ideally the food should be cut no larger than:

50 × 30mm

- If the food is too hard to push through the grid cook for approximately 10-15 minutes, then allow to cool in a refrigerator before processing.
- Always remove hard skins, stones, pips and seeds etc., from food before processing.

Note:

- Due to the various sizes and shapes of foods, the diced results will contain some misshapen pieces, this is normal.
- Foods such as cheese, ham, and chorizo will clog in the grid so are not recommended for use with this attachment.

27A The Express Dice can also be used to produce French fries, crudités and batons.

- 1 Fit the dicing grid without the dicing disc.
- 2 Then manually push the food through the grid without switching the appliance on.

Cleaning the grid


Use the end of the pusher to dislodge any food which may become trapped in the dicing grid.

28 Express Serve (if supplied)

- a Express serve drive shaft
- b Extension chute
- c Base
- d Slinger plate

- 1 Fit the drive shaft and bowl onto the power unit.
- 2 Fit the small drive shaft to the main shaft – **the Express serve will not operate unless fitted.**
- 3 Fit the required attachment/disc - do not apply excessive force. Refer to the Discs and Express Dice sections for further information, hints and tips.
- 4 Fit the lid.

Use in conjunction with the following:



Important - Dicer and Discs

- If the food is not exiting the food outlet, switch off and check that food is not clogging under the disc and the slinger plate is fitted. Clear any trapped food before continuing to process.

29 Storage Bag

Store your discs, dual whisk and dough tool in the bag supplied.

For safety reason the knife blade should be stored in the main bowl instead of the storage bag when not in use.

Care and Cleaning

- Always switch off and unplug before cleaning.
- **Handle the blade and cutting discs with care - they are extremely sharp.**
- Some foods may discolour the plastic. This is perfectly normal and will not harm the plastic or affect the flavour of your food. Rub with a cloth dipped in vegetable oil to remove the discolouration.

Power Unit

- Wipe with a damp cloth, then dry. Ensure that the interlock area ⑧ is clear of food debris.
- Do not immerse the power unit in water.
- Push any excess cord into the storage area at the back of the power unit ⑨.

Cleaning Instructions - Refer to the relevant Illustration **30**.

Service and Customer Care

UK

If you need help with:

- using your appliance or
- servicing, spare parts or repairs (in or out of guarantee)
- call Kenwood customer care on **0345 222 0458**. Have your model number (e.g. TYPE FDM71) and date code (5 digit code e.g. 21T04) ready. They are on the underside of the power unit.
- **spares and attachments**
- call 0844 557 3653.

Other countries

- If you experience any problems with the operation of your appliance, before requesting assistance refer to the 'Troubleshooting Guide' section in the manual or visit www.kenwoodworld.com.
- Please note that your product is covered by a warranty, which complies with all legal provisions concerning any existing warranty and consumer rights in the country where the product was purchased.

- If your Kenwood product malfunctions or you find any defects, please send it or bring it to an authorised KENWOOD Service Centre. To find up to date details of your nearest authorised KENWOOD Service centre visit www.kenwoodworld.com or the website specific to your Country.

- Designed and engineered by Kenwood in the UK.
- Made in China.



IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE ON WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEEE)

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Guarantee UK only

- If your food processor goes wrong within one year from the date you bought it, we will repair it (or replace it if necessary) free of charge provided:
- it has been used in accordance with these instructions.
- you have not misused, neglected, or damaged it;

- it has not been modified (unless by KENWOOD);
- it is not second hand;
- it has not been used commercially;
- you have not fitted a plug incorrectly; and
- **you supply your receipt to show when you bought it.**

This guarantee does not affect your statutory rights.

Recommended Usage Chart

Do not operate your appliance for longer than the times specified below without a rest period.

Do not exceed the maximum capacities stated in the chart below.




Processing continuously for longer periods can damage your appliance.

Processing information supplied is for guidance only and will vary depending on the exact recipe and ingredients being processed.

Do not process hot ingredients

| Tool/ Attachment | Function | | | |
|---------------------|---|------------------|---------------|---|
| | All in one cake mixes | Min - Max | 10 - 20 | 1.5kg total weight |
| | Pastry - rubbing fat into flour Adding water to combine pastry ingredients | Max Mid - Max | 10 10 - 20 | 340g flour weight |
| | Chopping fish and lean meat Pâtés and terrines | Max & P | 10 - 30 | 600g max lean beef |
| | Chopping vegetables | P | 5 - 10 | 100 - 500g |
| | Chopping nuts | Max | 30 - 60 | 100g - 200g |
| | Herbs | Max | 20 - 30 | 30-50g |
| | Pureeing soft fruit, cooked fruit and vegetables | Max | 10 - 30 | 1kg |
| | Mayonnaise | Max | 60 - 80 | 3-4 egg yolks |
| | Egg whites | Max | 90 - 150 | 5 (150g) |
| | Egg & sugar for fatless sponges | Max | 240 - 300 | 150g Egg 75g Sugar |
| | Cream | Mid - Max | 30 | 250 - 500 ml |
| | Creaming fat and sugar Heavier ingredients such as flour and dried fruit should be folded in by hand. | Max | 60 - 120 | 200g fat 200g sugar |
| | Yeasted mixes | Max | 60 | 600g flour weight 1kg total weight |
| | Grating and slicing firm food items - cheese, carrots, potatoes and foods of a similar texture | Max | 5 - 30 | Do not fill above the maximum capacity marked on the bowl |
| | Slicing softer food items - cucumbers and tomatoes | Low | 5 - 30 | |
| | Grates Parmesan cheese Raspberries | Max | 5 - 30 | |
| | Use to squeeze the juice from citrus fruits e.g. oranges, lemons, limes and grapefruits. | Low | 120 - 300 | - |

Recommended Usage Chart



| Tool/ Attachment | Function | | (Secs) | MAX |
|--|--|-----------------|---------------|---|
|  | Cold liquids and drinks (Add ice/frozen ingredients to goblet last) | Max | 30 - 60 | 1.5 litre |
| | Milkshake/Cold milk based mixtures | Max | 15 - 30 | 1 litre |
| | Ice crushing | P | 30 - 40 | 6 ice cubes (125g) |
| | Batter mix (Add liquid ingredients first) | Mid ↓ Max | 10 ↓ 50 | 1 litre |
| Plastic Blender - do not process hot ingredients | | | | |
| Thermoresist™ Glass Blender - We recommend that hot ingredients are allowed to cool before blending. However should you wish to process hot ingredients please read the Hot Blending Safety instructions. | | | | |
| Thermoresist™ goblet only | | | | |
|  | Stock based soups | Max | 30 - 60 | 1.2 litre |
| | Soups using milk | Max | 30 | 1 litre |
|  | Nuts | Max | 10 - 30 | 50g |
| | Coffee beans | Max | 30 | 50g |
| | Prune Marinade 250g clear sunny honey 25g small soft prunes 25ml cold water Refrigerate the ingredient overnight | P | 5 | 300g |
| | Processing spices Black peppercorns, cardamom seeds, cumin seeds, coriander seeds and fennel seeds | Max | 30 - 60 | 50g |
| | Grinding coffee beans | Max | | 50g |
|  | Chopping nuts | P | 15 - 30 | 50g |
| | Processing garlic cloves, fresh chillies and root ginger | P | 5 - 10 | 30g |
| | Fresh coconut | Max/P | 30 - 60 | 40g |
| | Drinks & smoothies | Max | 30 - 60 | 400ml |
| | Fruit and vegetables | Max | 60 - 120 | 600g |
|  | Use to cut a variety of foods such as carrot, courgette, cucumber, beetroot and apples into cubes. | Max | 5 - 30 | Do not fill above the maximum capacity marked on the bowl |
|  | Use to cut a variety of foods such as potato, carrot, courgette and cucumber into French Fries and crudités. | Manual | | |

| Troubleshooting Guide | | |
|---|--|---|
| Problem | Cause | Solution |
| The processor will not operate. | No Power. Bowl not fitted to power unit correctly. | Check processor is plugged in. Check bowl is located correctly and the handle is situated towards the right front hand corner. |
| | Bowl lid not locked on correctly. | Check that the lid interlock is located correctly into the handle area. The processor will not work if the bowl and lid are fitted incorrectly. |
| | Detachable drive shaft ⑤ not fitted to power unit. | Fit the detachable drive shaft ⑤ onto the power unit before fitting the bowl. The bowl tools and attachments will not operate unless the drive shaft is fitted. |
| Blender, Blend-Xtract 2GO or mill will not operate | Blender, Blend-Xtract 2GO or mill not locked on correctly. | Blender, Blend-Xtract 2GO or mill will not operate if fitted incorrectly to the interlock. |
| | Glass blender, Blend-Xtract 2GO or mill not assembled correctly. | Check blade assembly is fully tightened into the glass goblet, bottle or jar. |
| Processor stops during processing | Processor overloaded/ maximum capacities exceeded. | Check maximum capacities stated in the recommended usage chart. |
| | Lid unlocked. | Check lid is locked correctly. |
| Glass blender, Blend-Xtract 2GO or multi mill leaking from blade assembly base. | Seal missing Seal incorrectly fitted Seal damaged. | Check seal is fitted correctly and not damaged. To obtain a replacement seal see 'Service and customer care'. |
| Unit unstable/heavy vibrations åå | Sticky fruit/ingredients such as dates being processed. Speed selected too low. | For best results use 'Pulse' first to break down the ingredients and then continue processing on maximum speed. |
| Poor performance of tools/attachments | Refer to hints in relevant 'Using the attachment' section. Check attachments are assembled correctly. | |
| Weighing Function | | |
| Display screen freezes on [----] | The display screen will freeze during operation. | Normal operation. |
| | Display screen showing a minus reading due to display not 'zeroed' and either ingredients or the bowl/lid/attachment is removed. | Either zero the screen or replace the missing ingredients or refit the bowl/lid/attachment. |
| | Quantity weighed too small. | Use teaspoon and tablespoon measures for very small quantities. |
| Weight changed on display | Power unit moved during operation. | Always place the processor on a dry flat surface prior to weighing. Do not move the power unit during operation of the weighing function. Zero the display before weighing next ingredients |
| Display screen turned off | Power unit unplugged | Plug appliance in. |
| | The display screen will turn off automatically if the same weight reading is shown after 5 minutes. | Press the ON/ZERO button once and the display screen will light up. |
| Display showing [0 - Ld] | Weighing function overloaded | Do not exceed the maximum weighing capacity of 3Kg. |
| | Excessive force applied to power unit. | Do not subject the power unit to excessive force as this may damage the weighing sensor. |

دليل اكتشاف المشكلات وحلها

| المشكلة | السبب | الحل |
|---|---|------------------------------------|
| وظيفة الوزن | | شاشة العرض ثابتة على الوضع [- - -] |
| يثبت عرض شاشة العرض أثناء التشغيل. تعرض شاشة العرض قيمة سالبة وذلك يرجع إلى عدم إعادة تعيين الوزن إلى الصفر أولاً أو في حالة إزالة أي من المكونات أو السلطانية/الغطاء العلوي/الملحق. | أعيدى تعيين الشاشة إلى الصفر أو أعيدى المكونات أو أعيدى تركيب السلطانية/الغطاء العلوي/الملحق. | |
| استخدمي ملعقة صغيرة أو ملعقة كبيرة لوزن الكميات الصغيرة | الكمية الموزونة صغيرة جداً | |
| ضعي جهاز تحضير الطعام على سطح مستوي جاف قبل عملية الوزن. لا تحركي وحدة الطاقة أثناء استخدام وظيفة الوزن. قومي بتعيين الصفر على شاشة العرض قبل وزن المكونات التالية. | تم تغيير الوزن على شاشة العرض التشغيل | تم تغيير الوزن على شاشة العرض |
| أعيدى توصيل الجهاز بمصدر التيار الكهربى. | تم فصل التيار الكهربى عن وحدة الطاقة (الموتور) | تم إيقاف تشغيل شاشة العرض |
| اضغطي على زر ON/ZERO (تشغيل/صفر) مرة واحدة، يتم إضاءة شاشة العرض. | يتم إيقاف تشغيل شاشة العرض تلقائياً في حالة عرض نفس الوزن لمدة ٥ دقائق. | شاشة العرض تعرض القيمة [Ld - O] |
| لا تتجاوزي أقصى سعة لوظيفة الوزن وهي ٣ كيلوغرام. لا تضعى وزن كبير على وحدة الطاقة حيث قد يسبب ذلك تلف مستشعر الوزن. | تجاوز سعة وظيفة الوزن تم توجيه قوة مفرطة على وحدة الطاقة. | |






جدول توصيات الاستخدام

| الحد الأقصى الوزن | الحد الأقصى (ثانية) | الدليل | الوظيفة | الأداة/الملحق |
|--|------------------------|-------------------|---|---|
| ٦٠٠ غرام | ١٢٠ - ٦٠ | الحد الأقصى (Max) | الفواكه والخضروات |  |
| لا تتجاوزي السعة القصوى المشار إليها على السلطانية | ٣٠ - ٥ | الحد الأقصى (Max) | تستخدم لقطع مجموعة متنوعة من الأطعمة مثل الجزر والكوسة والخيار والشمندر والنفاح إلى مكعبات. |  |
| | | الدليل | تستخدم لقطع مجموعة متنوعة من الأطعمة مثل البطاطس، والجزر، والكوسة، والخيار إلى البطاطس المقلية والكرودينيس. |  |

دليل اكتشاف المشكلات وحلها





| المشكلة | السبب | الحل |
|--|---|--|
| جهاز تحضير الطعام لا يعمل. | الجهاز غير موصى بمصدر تيار كهربائي. السلطانية غير مرکبة على وحدة الطاقة (المotor) بشكل صحيح. | تحقق من السلك الكهربائي وأنه موصى بمنفذ التيار الكهربائي. تأكد من تركيب السلطانية بشكل صحيح وأن المقبس متوجه نحوية الركن الأمامي الآمن. |
| غطاء السلطانية غير مرکب بشكل صحيح. | غطاء السلطانية غير مرکب بشكل صحيح. | تأكد من تعشيق الغطاء العلوي بشكل صحيح في منطقة المقبس. لن يعمل جهاز تحضير الطعام في حالة تركيب السلطانية والغطاء العلوي بشكل غير صحيح. |
| المازج، المازج Blend-Xtract 2GO أو المطحنة لا تعمل | محور الدوران القابل للفصل ⑤ غير مركب بوحدة الطاقة. | ركي محور الدوران القابل للفصل ⑤ في وحدة الطاقة قبل تركيب السلطانية، لن تعمل أدوات السلطانية والملحقات إذا لم يتم تركيب محور الدوران. |
| المازج، المازج Blend-Xtract 2GO أو المطحنة لا تعمل | لا يمكن تجميع المازج الزجاجي أو جهاز Blend-Xtract 2GO أو المطحنة بشكل صحيح. | لن يعمل المازج، المازج Blend-Xtract 2GO أو المطحنة في حالة التركيب بشكل غير صحيح في موضع تعشيق القفل. |
| توقف جهاز تحضير الطعام أثناء التشغيل. | لا يمكن تجميع المازج Blend-Xtract 2GO أو المطحنة بشكل صحيح. | تحقق من أن مجموعة الشفرة مرکبة بحاكم في الدور الزجاجي أو الزجاجة أو الوعاء. |
| المازج الزجاجي، جهاز Blend-Xtract 2GO متعددة الاستخدامات بهم تسرب من قاعدة مجموعة الشفرات. | تجاوز حد التحمل لجهاز تحضير الطعام/تجاوز الساعات القصوى | تحقق من الساعات القصوى الموصى بها والمحددة في جدول السرعات. |
| الوحدة غير مستقرة/اهتزازات وحركة شديدة. | تم فتح الغطاء العلوي. | تأكد من قفل الغطاء العلوي بشكل صحيح. |
| لا تعمل الأدوات/الملحقات بشكل جيد. | حافة الإحكام غير مرکبة في حافة الإحكام غير مرکبة في موضعها جيداً. حافة الإحكام تالفة. | تحقق من تركيب حلقة الإحكام في موضعها الصحيح وبطريقة صحيحة وأنها غير تالفة. الحصول على حلقة إحكام لاستبدال الحلقة التالفة. راجع قسم الصيانة ورعاية العملاء |
| لا تعمل الأدوات/الملحقات بشكل جيد. | تحضير الفاكهة/المكونات اللازجة مثل البلح. السرعة المحددة بطيئة جداً. | للحصول على أفضل النتائج، استخدمي "التشغيل التناصي" أولاً لتكسير المكونات ثم تابعي التحضير بأقصى سرعة. |

جدول توصيات الاستخدام

| اللاده/ الملحق | الوظيفة | | (ثانية) | الحد الأقصى |
|---|---|---------------------------------|-------------------|-------------------------|
|  | استخدمي العصارة لتحضير العصير من الموالح، مثل البرتقال والليمون والليمون الحمضى والجریب فروت. | منخفض | ٢٠٠ - ١٢٠ | - |
|  | (أضيفي الثلج) المكونات المجمدة إلى الدورق كآخر مكونات | الحد الأقصى (Max) | ٦٠ - ٣٠ | ١.٥ لتر |
|  | الحليب المخفوق/الخلطات المستندة إلى حليب بارد | الحد الأقصى (Max) | ٣٠ - ١٥ | ١ لتر |
|  | جرش الثلج | P | ٤٠ - ٣٠ | ٦ مكعبات ثلج (١٢٠ غرام) |
|  | خلط المخفوقات (أضيفي المكونات السائلة أولاً) السوائل والمشروبات الباردة | المنتصف ↓ الحد الأقصى | ١٠ ↓ ٥٠ | ١ لتر |
| المازج البلاستيكي - لا تعالجي المكونات الساخنة | | | | |
| مازج Thermoresist™ الزجاجي - نوصي بترك المكونات الساخنة حتى تبرد قبل المزج. ومع ذلك، فإذا كنت ترغبين في تحضير المكونات الساخنة، يرجى قراءة تعليمات مزج المكونات الساخنة. | | | | |
| دورق Thermoresist™ فقط | | | | |
|  | الحساء القائم على المرق | الحد الأقصى (Max) | ٦٠ - ٣٠ | ١.٢ لتر |
|  | الحساء الذي يستخدم الحليب | الحد الأقصى (Max) | ٣٠ | ١ لتر |
|  | المكسرات | الحد الأقصى (Max) | ٣٠ - ١٠ | ٥٠ غرام |
|  | حبوب القهوة | الحد الأقصى (Max) | ٣٠ | ٥٠ غرام |
|  | ماريناد البرقوق المجفف ٢٥ جرام عسل نحل صافي ٢٥ جرام برقوق مجفف طري صغير ٢٥ مل ماء بارد احتفظي بالمكونات في الثلاجة طوال الليل | P | ٥ | ٣٠٠ غرام |
|  | معالجة التوابل فلفل أسود وبنجر الهيل والكمون والكزبرة والثمرة وقرون الفلفل الحار | الحد الأقصى (Max) | ٦٠ - ٣٠ | ٥٠ غرام |
|  | طحن حبوب القهوة | الحد الأقصى (Max) | ٦٠ - ٣٠ | ٥٠ غرام |
|  | فرم المكسرات | P | ٣٠ - ١٥ | ٥٠ غرام |
|  | فرم فصوص الثوم والفلفل الأحمر الطازج والزنجبيل | P | ١٠ - ٥ | ٣٠ غرام |
|  | جوز الهند الطازج | الحد الأقصى / (Max) | ٦٠ - ٣٠ | ٤٠ غرام |
|  | المشروبات والمشروبات ذات الرغوة | الحد الأقصى (Max) | ٦٠ - ٣٠ | ٤٠٠ مل |

جدول توصيات الاستخدام

لا تستخدمي الجهاز لأ زمنة أطول من تلك الموضحة أدناه دون السماح بفترات الراحة.
 لا تتجاوزي الساعات القصوى المذكورة في الرسم البياني أدناه. استمرارية معالجة المزيد من المكونات لفترة زمنية أطول قد يتسبب في تلف الجهاز.
معلومات المعالجة الموضحة هي إرشادية فقط، حيث تختلف الأزمنة والسرعات المستخدمة حسب الوصفة والمكونات المستخدمة.
لا تستخدمي مكونات ساخنة أثناء التحضير

| الحد الأقصى  | (ثانية)  | الحد الأقصى  | | الوظيفة | الأداة/الملحق |
|--|--|--|--|---|---|
| الوزن الإجمالي ١,٥ كغم | ٢٠ - ١٠ | الحد الأدنى - الحد الأقصى (Min - Max) | | خلطات الكعكات الجاهزة | |
| ٣٤٠ وزن الدقيق غرام | ١٠ ٢٠ - ١٠ | الحد الأقصى (Max) المنتصف - الحد الأقصى (Mid - Max) | | المعجنات - خلط السمن مع الدقيق إضافة الماء لدمج مكونات المعجنات |  |
| ٦٠٠ غرام لحم بقري طري | ٣٠ - ١٠ | الحد الأقصى ووضع التشغيل التبضي (Max & P) | | العجائن الهشة وأرغفة اللحم فرم الأسماك واللحوم | |
| ٥٠٠ - ١٠٠ غرام | ١٠ - ٥ | P | | فرم الخضروات | |
| ٢٠٠ - ١٠٠ غرام | ٦٠ - ٣٠ | الحد الأقصى (Max) | | فرم المكسرات | |
| ٥٠ - ٣٠ غرام | ٣٠ - ٢٠ | الحد الأقصى (Max) | | الأعشاب | |
| ١ كغم | ٣٠ - ١٠ | الحد الأقصى (Max) | | هرس الفواكه اللينة والفواكه والخضروات المطهية | |
| ٤-٣ صفار بيض | ٨٠ - ٦٠ | الحد الأقصى (Max) | | المايونيز | |
| ٥٠ (٥ غرام) | ١٥٠ - ٩٠ | الحد الأقصى (Max) | | بياض البيض | |
| ١٥٠ جرام بيض ٧٥ جرام سكر | ٣٠٠ - ٢٤٠ | الحد الأقصى (Max) | | البيض والسكر للكيك الاسفنجي الحالي من الدهون |  |
| ٥٠٠ - ٢٥٠ مل | ٣٠ | المنتصف - الحد الأقصى (Mid - Max) | | القشدة المكونات التخينية مثل الدقيق والفواكه المجففة يجب فركها باليدين لتصبح طيبة. | |
| ٥٠٠ مل سمن ٥٠٠ مل سكر | ١٢٠ - ٦٠ | الحد الأقصى (Max) | | خلط السمن مع السكر | |
| ٦٠٠ وزن الدقيق غرام الوزن الإجمالي ١ كغم | ٦٠ | الحد الأقصى (Max) | | الخلطات المخمرة |  |
| لا تتجاوزي السعة القصوى المشار إليها على السلطانية | ٣٠ - ٥ | الحد الأقصى (Max) | | بشر وقطيع المكونات الغذائية الصلبة - الجبن والجزر والبطاطس والأغذية التي لها نفس ذلك القوام. |  |
| | ٣٠ - ٥ | منخفض | | قطيع المكونات الغذائية اللينة إلى شرائح - الخيار والطماطم |  |
| | ٣٠ - ٥ | الحد الأقصى (Max) | | بشر جبن البارميزان كشط البطاطس |  |

الصيانة ورعاية العملاء


- إذا واجهت أي مشاكل في تشغيل جهازك، فقبل طلب المساعدة، راجع قسم "دليل استكشاف المشكلات وحلها" في هذا الدليل أو قم بزيارة الموقع الإلكتروني www.kenwoodworld.com.
- للحصول على معلومات الخدمة أو الضمان، يرجى الرجوع إلى نشرة تدبير السلامة المنشورة أو زيارة www.kenwoodworld.com.
- تمت الأعمال الهندسية والتصميم من قبل شركة Kenwood في المملكة المتحدة.
- صنع في الصين.

Express Serve 28 (في حالة تزويدك داخل صندوق البيع)

- a محور دوران ملحق Express serve
- b أنبوب التمديد
- c القاعدة
- d سطح الرفع

- ١ ركيبي محور الدوران والسلطانية على وحدة الطاقة (الموتور).
- ٢ ركيبي محور الدوران الصغير مع المحور الرئيسي - لن يعمل ملحق Express serve السريعة إذا لم يتم تركيبه.
- ٣ ركيبي الملحق/القرص المطلوب - لا تستخدمي القوة المفرطة. ارجع إلى أقسام الأقراص Express Dice و Express Dice و Express Dice و Express Dice للحصول على المزيد من المعلومات والتلميحات والنصائح.
- ٤ ركيبي الغطاء العلوي.

لا تستخدمي القوة المفرطة مع ما يلي:



مهم - القطاعة والأقراص

- إذا كان الطعام لا يخرج من مخرج الطعام، أوقفي التشغيل وتحقق من عدم انتشار الطعام أسفل القرص ومن تركيب سطح الرفع. أزيلي أي طعام محشور قبل مواصلة التحضير.

29 حقيقة التخزين

قومي بتخزين الأقراص ومضرب البيض المزدوج وأداة العجن في الحقيقة المرفقة.

لداعي السلامة، يجب تخزين شفرة السكين في السلطانية الرئيسية بدلاً من حقيقة التخزين عندما لا تكون قيد الاستخدام.

العناية والتنظيف

- أوقفي دائمًا تشغيل الجهاز وأفصليه عن مصدر التيار الكهربائي قبل التنظيف.
- توخي الحذر أثناء التعامل مع الشفرات وأقراص التقطيع - هذه الأجزاء حادة جداً.
- قد تؤثر بعض الأغذية على لون البلاستيك. هذا أمر طبيعي تماماً ولا يضر بالبلاستيك او يؤثر على تكهة الطعام. امسحي البلاستيك بقمash مغمومس في زيت نباتي لإزالة تغيير اللون.

وحدة الطاقة (الموتور)

- امسحها بقطعة قماش مبللة، ثم جففيها. تأكدي من أن منطقة القفل ⑥ خالية من بقايا الطعام.
- لا تقومي بغير وحدة الطاقة في الماء.
- قومي بلف السلك الزائد في مكان تخزين السلك أسفل وحدة الطاقة ⑨.

ارجعي إلى الرسم التوضيحي ذي الصلة

30

27 Express Dice (في حالة تزويده داخل صندوق البيع)

- a قرص التقاطع
- b شبكة التقاطع
- c عصا الدفع للتقاطع

مهم


- تم تصميم قرص التقاطع للاستخدام مع ملحق التقاطع فقط.
- يجب عدم استخدام "عصا الدفع للتقاطع" إلا مع شبكة التقاطع، حيث سيؤدي استخدامها بدون تركيب شبكة التقاطع إلى تلف الجزء السفلي من عصا الدفع.

لاستخدام Express Dice

- 1 ركيبي حمور الدوران والسلطانية على وحدة الطاقة (الموتور).
- 2 أصيبي قرص التقاطع وركبي الغطاء العلوي.
- 3 ركيبي شبكة التقاطع في أنبوب التغذية.
- 4 قومي بتشغيل عصا الدفع للتقاطع واستخدامها لتحضير الطعام من خلال شبكة التقاطع.

تلميحات ونصائح

- للمساعدة في تجهيز مكان التحضير ضعي كلتا يديك أعلى عصا دفع الطعام وأضغطي لأسفل بقوّة.
- للحصول على أفضل النتائج ، استخدم الفواكه والخضروات الطازجة.
- لمنع احتشام الطعام، لا تكسي الطعام في أنبوب التغذية - من الناحية المثالية، يجب عدم قطع الطعام إلى قطع أكبر من:



- إذا كان من الصعب جداً دفع الطعام خلال الشبكة لمدة ١٥-١ دقيقة، فاتركيه يبرد في الثلاجة قبل التحضير.
- احرصي دائمًا على إزالة القشور الصلبة والنوى والبذور وما إلى ذلك من الطعام قبل التحضير.

- بسبب الأحجام والأشكال المختلفة للأطعمة، فإن نتائج الأطعمة المقطعة تحتوي على بعض القطع المشوهة، وهذا أمر طبيعي.
- تسبب الأطعمة مثل الجبن ولحم الخنزير والشوريزو انسداد الشبكة لذا لا ينصح باستخدامها مع هذا الملحق.

27A يمكن أيضًا استخدام ملحق Express Dice في تحضير البطاطس المقليّة والكريديتيس والباتون.

- 1 ركيبي شبكة التقاطع بدون قرص التقاطع.
- 2 ثم أدعقي الطعام يدوياً عبر الشبكة بدون تشغيل الجهاز.

تنظيف الشبكة

- استخدمي طرف عصا دفع الطعام لإخراج أي طعام قد يكون محشوّزاً في شبكة التقاطع.

- لاحتياجك أنه عند تعبئة الزجاجة إلى السعة القصوى (٤٠٠ مللي)، فإن الكمية تكون كافية للتقطيع الشخصين إذا كنت لا تنوين استهلاك المشروب مباشرة فيجب الاحتفاظ به في الثلاجة.
- تأكدي أن قوام المشروب رقيق بالقدر الكافي حتى تتمكنين من شربه عن طريق الفتحة الصغيرة الموجودة في غطاء التوزيع العلوي.
- لتحضير مشروب بقوام خفيف أضيفي المزيد من السوائل.
- بعد الخلط لفترة من الوقت، قد تكون بعض المكونات ذات طبيعة برغوة بشكل تام نتيجة وجود بذور أو تكون المكونات ذات طبيعة ليفية.
- قد تتفصل بعض المشروبات إذا تركت لفترة بعد الخلط، لذلك يكون من الأفضل تناولها مباشرة. يجب تقليل المشروبات المنفسقة قبل تناولها.
- عند ترطيب غطاء التوزيع العلوي حافظي على وضع الزجاجة في وضع رأسى.

استخدام غطاء فتحة الشرب

- 1 ركيبي الغطاء العلوي وثبتيه من خلال لفة في اتجاه عقارب الساعة.
- 2 إذا أردت تناول المشروبات ذات الرغوة، ببساطة ارفعي الغطاء العلوي.
- 3 يمكن شرب المشروب مباشرة من الزجاجة.

26 مستخلص العصير (في حالة تزويده داخل صندوق البيع)

- a عصا دفع الطعام
- b الغطاء العلوي للعصارة
- c مزيل اللب
- d أسطوانة المصفاة
- e السلطانية
- f صنبور العصير

لاستخدام مستخلص العصير

- ركبي سلطانية العصارة في وحدة الطاقة (الموتور) ولفيها في اتجاه عقارب الساعة إلى أن تسقّر في موضعها - يجب أن يكون الصنبور على الجانب الأيسر عند تركيب السلطانية بشكل صحيح.

- ضعify مزيل اللب في أسطوانة المصفاة - مع ضمان وضع الإلستنة مع الفتحات الموجودة في أسفل الأسطوانة.
- 3 ركيبي أسطوانة المصفاة
 - 4 ركيبي الغطاء العلوي للملحق - ولفيه في اتجاه عقارب الساعة إلى أن يسقّر في موضعه، لن تعمل العصارة إذا لم تكن السلطانية أو الغطاء العلوي مركبين بشكل صحيح في القفل.

- 5 ضعي زجاجة أو وعاء مناسب تحت مخرج العصير.
- 6 أطقطعي الطعام ليناسب أنبوب التغذية.
- 7 قومي بالتشغيل وادفعي لأنسفل بشكل متساوٍ باستخدام عصا دفع الطعام - يحضر ووضع أصابعك في أنبوب التغذية. حضري المزيج تماماً قبل إضافة المزيد.
- بعد إضافة القطعة الأخيرة، اتركي المصارة تعمل لمدة ٣٠ ثانية أخرى لاستخراج كل العصير من أسطوانة المصفاة.

- إذا بدأت العصارة في الاهتزاز، أوقفي تشغيلها وأنفّري اللب من الأسطوانة. نهئ العصارة إذا أصبح توزيع اللب غير متساوٍ.
- قد تؤدي بعض الأطعمة شديدة الصلابة إلى بطء العصارة أو توقفها. إذا حدث هذا أوقفي تشغيل العصارة وفك المصفاة.
- أوقفي التشغيل ونظفي جامع اللب بشكل دوري أثناء الاستخدام.

تلميحات ونصائح

- قبل التحضير، أزيلي النوى والبذور (مثل الفلفل والبطيخ والبرقوق) والقشور القاتية (مثل البطيخ والأناناس). لا تحتاجين إلى تقطير أو إزالة لب التفاح والكمثرى.
- استخدمي الفواكه والخضروات الطازجة والمتماسكة.

21 عصارة الموالح (في حالة التزويد داخل صندوق البيع)

- a مخروط العصر
- b المصفاة

استخدام عصارة الموالح

- ١ ركبي محور الدوران والسلطانية في وحدة الطاقة (الموتور).
- ٢ ركبي المصفاة في السلطانية - تأكدي من استقرار مقبس المصفاة في مواضعه مباشرة على مقبض السلطانية.
- ٣ ركبي مخروط العصر على محور الدوران وأديريه حتى يستقر تماماً في القاء.
- ٤ قطعي شار الفواكه إلى نصفين. ثم شغلي الجهاز واضغطي الفاكهة على مخروط العصر.
- لن تعمل العصارة في حالة تركيب المصفاة بشكل غير صحيح.

تلميحات ونصائح

- للحصول على الأداء الأمثل عند تحضير التوابل ننصحك بعدم تحضير أكثر من ٥٠ غرام من المكونات في المرة الواحدة داخل المطحنة.
- تتحقق قرون التوابل الكاملة بتكهتها فترة زمنية أطول من التوابل المطحونة لذلك فمن الأفضل طحن كمية صغيرة من قرون التوابل الكاملة لاستخدامها وذلك للاحتفاظ بالنكهة.
- للحصول على أقصى نكهة وزيوت أساسية من قرون التوابل الكاملة من الأفضل تحميص التوابل قبل طحنها.
- لا تتحضير جذور الكركم الجافة بواسطة المطحنة حيث أنها صلبة جداً وقد تتلف الشفرات.
- قطعي الزنجبيل إلى قطع صغيرة قبل معالجته.
- للحصول على أفضل النتائج ننصحك باستخدام السلطانية الأساسية عند فرم الأعشاب.

تلميحات ونصائح

- للحصول على أفضل النتائج، خزني الفاكهة واعصريها في درجة حرارة الغرفة، أيضاً لبني الفاكهة قبل عصرها عن طريق دحرجتها على سطح منضدة العمل مع الضغط عليها براحة كفك.
- للمساعدة في استخدام العصير، حركي الفاكهة من جانب لأخر أثناء العصر.
- عند عصر كمية كبيرة من الفاكهة، أفرغي المصفاة بانتظام لتجنب تراكم آب ويندر الفاكهة.

22 - 23 المفرمة / المطحنة الصغيرة (في حالة

التزويد داخل صندوق البيع)

- a الوعاء
- b حلقة الإحكام
- c وحدة الشفرات

- ١ ضعي المكونات في وعاء الطحن.
- ٢ ركبي حلقة الإحكام في وحدة الشفرات.
- ٣ أقلبي وحدة الشفرات. ضعيها داخل الوعاء بحيث يكون اتجاه الشفرات لأسفل.
- ٤ اربطي وحدة الشفرات في الوعاء بإحكام باستخدام أصابعك.
- راجعي الرسوم التوضيحية الموجودة على الجانب السفلي لمجموعة وحدة الشفرات وهي كالتالي:

■ = موضع الفتح

■ = موضع القفل

- ٥ ضعي المطحنة في وحدة الطاقة (الموتور) ولفيها في اتجاه عقارب الساعة إلى أن تستقر في موضعها.
- ٦ حددي السرعة القصوى أو استخدمي وظيفة التشغيل النبضي (P).

تلميحات ونصائح

- غذاء الرضيع/المهروبات - اتركي الأطعمة المطهية لتبرد في درجة حرارة الغرفة قبل معالجتها في المطحنة.
- للحصول على أفضل النتائج ننصحك باستخدام السلطانية الأساسية عند فرم الأعشاب.

25 المازج Blend-Xtract 2GO (في حالة تزويد به)

داخل صندوق البيع)

- a غطاء التوزيع العلوي
- b زجاجة المازج
- c حلقة الإحكام
- d وحدة الشفرات

- ١ أضيفي المكونات إلى الزجاجة حتى علامة المستوى ٤٠٠ مللي.
- للحصول على أفضل أداء للمزج، أضيفي دائماً الثلج/المكونات المجمدة إلى زجاجة المازج أولاً.
- عند إضافة المكونات المجمدة (مثل الفواكه المجمدة أو الزيادي أو الآيس كريم أو الثلج)، فلا تقومي بمزج أكثر من ٦٠ غرام أو ٣ مكعبات ثلج.
- لا تمزجي مكونات مجده دون إضافة سائل.
- ٢ ركبي حلقة الإحكام على وحدة الشفرات مع التأكد من استقرار حلقة الإحكام في موضعها بشكل صحيح داخل التجويف.
- إذا كانت حلقة الإحكام تالفة أو غير محكمة بشكل صحيح فسوف يحدث تسربها.
- ٣ امسكي بالجانب السفلي لوحدة الشفرات وافخضيها داخل الزجاجة، بحيث تكون الشفرات موجهة لأسفل.
- ٤ اربطي حامل الشفرات في الزجاجة، عن طريق اللف في اتجاه عقارب الساعة حتى موضع القفل.
- رجبي المازج على وحدة الطاقة ثم أديريه في اتجاه عقارب الساعة حتى يتم إحكام القفل.
- ٥ حددي السرعة القصوى. اتركي المكونات قيد الخلط إلى أن تتكون الرغوة.
- بمجرد وصول المشروب إلى القوام المطلوب، يمكنك استخدام وظيفة التشغيل النبضي (P) للتأكد من مزج جميع المكونات تماماً.

17 مضرب البيض المزدوج

- ١ ركيبي السلطانية على وحدة الطاقة (الموتور) ثم ركيبي محور الدوران القابل للفك والتركيب.
 - ٢ ادفعي كل مضرب بإحكام داخل رأس الدوران.
 - ٣ ركيبي مضرب البيض من خلال لفة بجذر حتى يسقط على محور الدوران.
 - ٤ أضيفي المكونات.
 - ٥ ركيبي الغطاء العلوي - مع التأكيد من استقرار طرف محور الدوران في مركز الغطاء العلوي.
 - ٦ شفني الجهاز.
- هام

٧ مضرب البيض غير مناسب للاستخدام مع خلطات الكعكات الجاهزة حيث أن قوام هذه الكعكات ثخين وسوف يتسبب في تلف المضرب. استخدمي دائمًا نصل السكين.

تلميحات ونصائح

- يمكن الحصول على أفضل النتائج عندما تكون درجة حرارة البيض هي نفس درجة حرارة الغرفة.
- تأكدي من نظافة السلطانية ومضرب البيض وعدم وجود أي دهون قبل الخفق.
- مزج السمن/الزبد مع السكر**
- للحصول على أفضل النتائج، يترك السمن/الزبد ليصبح طرياً في درجة حرارة الغرفة (٢٠ درجة مئوية) قبل الخفق. لا تستخدمي السمن/الزبد مباشرةً بعد إخراجه من الثلاجة لأن ذلك سيؤدي إلى تلف المضرب.
- المكونات الخثينة مثل الدقيق والفواكه المجففة يجب فركها باليد لتصبح طرية.
- لا تتجاوزي الساعات القصوى الموصى بها أو فترات المعالجة المحددة في جدول السرعات الموصى بها.

الأقراص 18 - 19 - 20

- ١ كبي محور الدوران والسلطانية في وحدة الطاقة (الموتور).
- ٢ امسكي قرص التقطيع من المقابض المركبزي ثم ضعي القرص على محور الدوران مع توجيهه السطح الملامن لأعلى.
- ٣ ركيبي الغطاء العلوي.
- ٤ ضعي الطعام في أنبوب التغذية. اختاري حجم أنبوب التغذية الذي تريدين استخدامه.
- ٥ لاستخدام أنبوب التغذية الصغير - ضعي أولاً عصا دفع الطعام الكبيرة داخل أنبوب التغذية. يستخدم المكونات الرقيقة المفردة.
- ٦ لا تستخدمي عصا الدفع الصغيرة بدون تركيب عصا الدفع الأكبر، وإلا فإن الجزء السفلي من عصا الدفع قد يتلف.
- ٧ لاستخدام أنبوب التغذية الكبير - استخدمي كلا نوعي عصا دفع الطعام معاً.
- ٨ شفني الجهاز مع دفع الطعام بالتساوي بواسطة عصا دفع المكونات.
- ٩ اخرحي ووضع أصابعك داخل فتحة أنبوب التغذية .

تلميحات ونصائح

- استخدمي مكونات طازجة.
- لا تقطعني الطعام إلى قطع صغيرة جداً. اجعلني عرض (مقلع) أنبوب التغذية ممتليء بشكل متساو. يحول ذلك دون انزلاق الطعام على الجوانب أثناء تحضير الطعام.
- الطعام الموضوع بشكل رأسى يخرج قصيراً عن الطعام الموضوع بشكل أفقي.
- تبقى هناك دائماً كمية صغيرة من الفضلات على سطح التقطيع أو في السلطانية بعد تحضير الطعام.

14B المازاج البلاستيكي (في حالة التزويد داخل صندوق البيع)

الرسم التوضيحي 14B

- ١ للتجميع والاستخدام - ارجع إلى الرسوم التوضيحية ومخطط الاستخدام الموصى به للمازاج.
- ٢ ضعي جميع المكونات في الدورق.
- ٣ ركيبي الغطاء العلوي على الدورق وقومي بلفه في اتجاه عقارب الساعة إلى أن يسقّر في موضعه.
- ٤ ركيبي المازاج في وحدة الطاقة (الموتور) ولفيه في اتجاه عقارب الساعة إلى أن يسقّر في موضعه.
- ٥ لن يعمل الجهاز في حالة تركيب المازاج بشكل غير صحيح مع تعشيق القفل.

تلميحات ونصائح

- عند تحضير المايونيز، ضعي كل المكونات، باستثناء الزيت، في المازاج.
- مع تشغيل الجهاز:

 - **المازاج الزجاجي-** أزيلي غطاء التعبئة وصبِي الزيت من خلال الفتحة الموجودة في الغطاء العلوي.
 - **المازاج البلاستيكي -** صبِي الزيت من خلال فتحة إضافة المكونات بالتنقية في الغطاء العلوي.

- قد تحتاج الخلطات السميكة مثل المعجنات الهشة والمغموسات إلى تقطيع. إذا وجدت صعوبة في تحضيرها، أضيفي المزيد من السوائل.
- غير منصوح بطحن التوابل فقد تؤدي إلى إحداث أضرار بالأجزاء البلاستيكية.

15 سكين التقاطع

اتبعي التعليمات الواردة في قسم "استخدام جهاز تحضير الطعام".

تلميحات ونصائح

- للحصول على قوام خشن، استخدمي وضع التشغيل النبضي.
- قطعي الطعام مثل اللحم، الخنزير، الخضروات إلى مكعبات بطول ٢ سم.
- يجب تكسير السكاكوته إلى قطع صغيرة وإضافتها عن طريق غطاء أنبوب التغذية ثناء تشغيل الجهاز.
- توخي الحذر حتى لا تتجاوزي الفترة المطلوبة لتحضير الطعام.
- عند تحضير المعجنات استخدمي الدهون مباشرةً من المجمد مع تقطيعها في صورة مكعبات بحجم تقريري ٣ سم.
- للحصول على أفضل النتائج عند تحضير الفاكهة/المكونات اللزجة مثل البح، استخدمي "التشغيل النبضي" أولاً لتكسير المكونات ثم تابعي التحضير بأقصى سرعة.

16 أداة العجين

تستخدم مع خلطات العجين المخمرة.
اتبعي التعليمات الواردة في قسم "استخدام جهاز تحضير الطعام".

تلميحات ونصائح

- لا تعالجي القواكه لفترة أطول من ٦٠ ثانية.
- ضعي المكونات الصلبة في السلطانية وأضيفي السائل عن طريق غطاء فتحة التعبئة ثناء تشغيل الجهاز. أستمري في التشغيل حتى تكون كرات لدنة من العجين.
- أعيدي العجين بيديك فقط. غير منصوح بإعادة العجين في السلطانية حيث قد يؤدي ذلك إلى عدم استقرار جهاز تحضير الطعام.

استخدام جهاز تحضير الطعام

الرسم التوضيحي ③ -

- ١ ركبي محور الدوران في وحدة الطاقة (المotor).
- ٢ ثم ضعي السلطانية في وحدة الطاقة (المotor) وقومي بتدويرها في اتجاه عقارب الساعة حتى يستقر في موضعه، ثم اتبعي الخطوات من ٢ إلى ٤ الموضحة ضمن "استخدام وظيفة الوزن".
- ٣ ركبي الملحظ على محور الدوران الموجود في السلطانية.
- ٤ ركبي دائماً السلطانية والملحظ في جهاز تحضير الطعام قبل إضافة المكونات.

استخدام الملحقات

راجعي جدول توصيات الاس تخدام لمعرفة تفاصيل استخدام كل ملحق.

14A المازج الزجاجي (في حالة التزويد داخل صندوق البيع)

استخدام المازج

الرسم التوضيحي 14A

- ١ ركبي حلقة الإحكام على وحدة الشفرات - مع التأكيد من استقرار حلقة الإحكام في موضعها بشكل صحيح داخل التجويف.
- ٢ إذا كانت حلقة الإحكام تالفة أو غير محكمة بشكل صحيح فسوف يحدث تسرباً.
- ٣ اربطي الدورق على وحدة الشفرات. راجعي الرسم التوضيحي الموجودة على الجانب السفلي لوحدة الشفرات وهي كالتالي:

 - = موضع الفتح
 - = موضع القفل

- ٤ ضعي المكونات داخل الدورق.
- ٥ ركبي الغطاء العلوي على الدورق وادفعيه لأسفل حتى يستقر في موضعه. ركبي غطاء، فتحة التعبئة ▪ ضعي المازج على وحدة الطاقة (المotor) ثم حاذني العلامة ■ الموجودة على المازج مع العلامة ▪ الموجودة على وحدة الطاقة (المotor) ثم لفني المازج في اتجاه عقارب الساعة حتى يستقر في موضع القفل ▪.
- ٦ لن يعمل الجهاز في حالة تركيب المازج بشكل غير صحيح مع تعشيق القفل.

- ٤ وصلني الجهاز مع مصدر التيار الكهربائي ثم شغلي الجهاز وحددي السرعة المطلوبة. (راجع جدول توصيات الاستخدام).

لا تستخدمي الغطاء العلوي لتشغيل جهاز تحضير الطعام، استخدمي دائمًا مفتاح تحكم السرعات On/Off.

- ٥ لن يعمل جهاز تحضير الطعام في حالة تركيب السلطانية أو الغطاء العلوي بطريقة غير صحيحة في موضع تعشيق القفل. تأكدي من توجيه أنبوب التغذية و MCP من السلطانية إلى الجانب الأيمن للجهاز.
 - ٦ استخدمي مفتاح وضع التشغيل التبضي (P) للتشغيل لفترات قصيرة. يجعل وضع التشغيل التبضي طوال فترة الضغط على مفتاح التحكم.
 - ٧ اتبعي الخطوات السابقة بترتيب معكوس لإزالة الغطاء العلوي، الملحقات والسلطانية.
 - ٨ أوقفي دائمًا تشغيل الجهاز قبل إزالة الغطاء العلوي.
- ملاحظة هامة**
- ٩ جهاز تحضير الطعام غير ملائم لطحن حبوب القهوة أو تحويل حبيبات السكر إلى سكر بودرة.
 - ١٠ عند إضافة روح أو نكهة اللوز للخلطات، تجنبي ملامسته مع البلاستيك حيث قد يؤدي ذلك إلى ترك علامات مستديمة على البلاستيك.

وظيفة الوزن

الرسم التوضيحي 4

جهاز تحضير الطعام مجهز بوظيفة وزن داخلية وذلك لوزن المكونات مباشرة داخل السلطانية أو دورق الميسيل.

- ١ سعة الوزن القصوى ٣ كغم.

استخدام وظيفة الوزن

- ٢ ركبي دائماً محور الدوران والسلطانية والملحق أو دورق الخلط على وحدة الطاقة قبل إضافة المكونات.
- ٣ وصلني الجهاز بتيار الكهربائي - تبقى شاشة العرض فارغة.
- ٤ اضغط على زر ON/ZERO (تشغيل/صفر) مرة واحدة. يتم إضافة شاشة العرض.
- ٥ اضغط على زر (kg/lb) زكغم/رطلس لتحديد وحدة الجرام أو الأونص. التعين الافتراضي على الشاشة بمجرد التشغيل هو g/kg (كغم/غر).
- ٦ خطوة الوزن الخاصة بالوحدة هي ١ غ ويوصى باستخدام وحدة ملعة صغيرة/ملعة كبيرة لقياس الكبيات الصغيرة.
- ٧ لتعيين الصغر اضغط على زر ON/ZERO (تشغيل/صفر) مرة واحدة.
- ٨ اوزني المكونات المطلوبة مباشرة في السلطانية أو الدورق.
- ٩ بعد وزن جميع المكونات، ركبي الغطاء العلوي وحددي سرعة لتشغيل جهاز تحضير الطعام.
- ١٠ لن يتم عرض وزن أي مكونات تتم إضافتها من خلال أنبوب إدخال الطعام أثناء تشغيل جهاز تحضير الطعام.
- ١١ يمكن إيقاف تشغيل شاشة العرض يدوياً بالضغط مع الاستمرار على زر ON/ZERO (تشغيل/صفر) لبضعة ثوان.
- ١٢ راجعي دليل استكشاف المشكلات وحلها إذا واجهتي أي مشاكل في تشغيل وظيفة الوزن.

A - ملحقات قياسية

- (15) شفرة السكين
- (16) اداة العجن
- (17) خفافه البيض الثانية
- (18) قرص القطع الرفيع/القطيع الطولي (البشر) ٤ مم
- (19) قرص القطع الرفيع/القطيع الطولي (البشر) ٢ مم

ليس بالضرورة تزويد كل الملحقات المدرجة أدناه داخل عبوة بيع جهاز تحضير الطعام. تختلف الملحقات تبعاً لاختلاف موديلات الجهاز. يرجى زيارة www.kenwoodworld.com للحصول على معلومات حول كيفية شراء ملحق غير مزود في صندوق بيع الجهاز.

B - ملحقات اختيارية

- (20) قرص البشر الناعم جداً (في حالة التزويد داخل صندوق البيع)
- (21) عصارة مواليح (في حالة التزويد داخل صندوق البيع)
- (22) القطاععة/المطحنة الصغيرة الزجاجية (في حالة التزويد داخل صندوق البيع)
- (23) القطاععة/المطحنة الصغيرة البلاستيكية (في حالة التزويد داخل صندوق البيع)
- (24) المفرمة / المطحنة الصغيرة (في حالة التزويد داخل صندوق البيع)
- (25) Blend-Extract 2GO (في حالة التزويد داخل صندوق البيع)
- (26) مستخلص العصير (في حالة التزويد داخل صندوق البيع)
- (27) Express Dice (في حالة التزويد داخل صندوق البيع)
- (28) ملحق Express Serve (في حالة التزويد داخل صندوق البيع)
- (29) حقيبة التخزين (في حالة التزويد داخل صندوق البيع)
- (30) الملعقة البلاستيكية

- (1) عصا دفع الطعام
- (2) أنبوب التغذية
- (3) الغطاء العلوي
- (4) السلطانية
- (5) محور دوران
- (6) وحدة الطاقة (الموتور)
- (7) مفتاح التحكم في السرعة/ التشغيل التبضي
- (8) أقفال الأمان
- (9) مخزن السلك (في الخلف)

وظيفة الوزن

- (10) زد #/kg (كغم/رطل)
- (11) زد on/zero (تشغيل/صفر)
- (12) شاشة العرض
- (13) سطح الوزن

14A مازج Thermoresist™ الزجاجي

(في حالة التزويد داخل صندوق البيع)

- a فتحة التعبئة
- b غطاء
- c الدورق الزجاجي
- d حلقة إحكام الإغلاق
- e وحدة الشفرة
- f القاعدة
- g هوايات فتحة التعبئة

14B المازج البلاستيكي

(في حالة التزويد داخل صندوق البيع)

- a دورق مع شفرة ثابتة.
- b الغطاء العلوي المزود بفتحة إضافة المكونات بالتنقيط

Express Serve ملحق

- تجنب ملامسة الأجزاء المتحركة. ضعي أصابعك خارج فتحة مخرج الطعام.
- لا تشغلي الجهاز عند استخدام القطاع أو الأقراص بدون تركيب سطح الرفع. إذا لم يتم تركيب سطح الرفع فسوف تجمع الأطعمة تحت قرص التقطيع ولا تخرج من مخرج الطعام، مما يؤدي إلى تلف الملحق.
- عصارة الموالح غير مصممة للاستخدام مع Express Serve. استخدمي عصارة الموالح دائمًا مع السلطانية الرئيسية.

التنظيف

- امسحي وحدة الطاقة (الموتور) ورأس دوران الخفاقة بقطعة قماش مبللة، ثم جففيهما. تأكدي من خلو منطقة الغلق من بقايا الطعام.
- لا تغمسي وحدة الطاقة (الموتور) أو مجموعة الشفرات أو قاعدة المازج في الماء.
- السلطانية والغطاء العلوي وعصا دفع الطعام وجميع الملحقات/الأدوات ما عدا مجموعة الشفرات والمازج مناسبة للغسيل اليدوي أو في غسالة الأطباق.
- يجب تنظيف مجموعة الشفرات وشطفها تحت الماء الجاري.
- المازج - املئيه بالماء الدافئ، وركبي الغطاء العلوي، ثم شغلي الجهاز لمدة ٢٠-٣٠ ثانية. أفرغيه، ثم اشطفيه. إذا كان مازجًا متسخًا، استخدمي فرشاة. امسحيه، ثم اتركيه حتى يجف في الهواء.

قبل توصيل الجهاز بمصدر التيار الكهربائي

- تأكدي من تمايز مواصفات مصدر التيار الكهربائي لديك مع المواصفات الموضحة على الجانب السفلي للجهاز.
- هام - المقبس والمنصهر الكهربائي
- اللوان الأسلاك الموجودة في السلك الكهربائي هي كالتالي:
 - أزرق = متوازن
 - بني = كهرباء حية
- إذا كان القابس المزود في جهازك به مصهر مركب وتعطل هذا المصهر، فيجب استبداله بمصهر مماثل له بنفس تغير الأمبيرية.
- في حالة الحاجة إلى استبدال المقبس أو السلك الكهربائي، فيجب استبدالهما وتركيبهما من قبل مركز صيانة متخصص معتمد لدى Kenwood.
- ملاحظة:
- بالنسبة إلى المقابس غير القابلة لإعادة تركيب الأسلاك الجديدة بها، يجب إعادة تثبيت غطاء المنصهر الكهربائي عند استبداله. في حالة فقد غطاء المنصهر الكهربائي، يجب عدم استخدام المقبس إلا أن يتم الحصول على بديل. يتم تحديد غطاء المنصهر الكهربائي الصحيح حسب اللون ويمكن الحصول على بديل من مركز صيانة متخصص معتمد لدى Kenwood (يرجى مراجعة قسم الخدمة).
- إذا تم قطع مقبس غير قابل لإعادة تركيب الأسلاك الجديدة به، فيجب تدميره على الفور. إذا تم إدخال قابس غير قابل لإعادة التمديد عن غير قصد في مخرج المقبس، فقد قد يتسبب خطأ حدوث صدمة كهربائية.
- يتوافق هذا الجهاز مع تسميات الاتحاد الأوروبي 2004/1935 المتعلقة بالمواد والأجسام الملامسة مع الأطعمة.

قبل الاستعمال للمرة الأولى

- ١ أزيلي أغطية النصل البلاستيكية عن سكين التقطيع. توخي الحذر فسكين التقطيع حاد جداً. يجب التخلص من هذه الأغطية حيث أنها مزودة لحماية سكين التقطيع أثناء التصنيع والنقل.
- ٢ اغسلي الأجزاء "راجعي قسم الرعاية والتنظيف".

ملحقات المطحنة

- يحذر تركيب وحدة الشفرات على وحدة الطاقة (المotor) بدون تركيب وعاء الطحن / الغطاء العلوي.
- يحذر فك وعاء الطحن/الغطاء العلوي عن المطحنة أثناء تركيبها في الجهاز.
- لا تلمسي الشفرات الحادة - ابعدي وحدة الشفرات عن متناول الأطفال.
- يحذر إزالة المطحنة قبل توقف الشفرات عن الدوران تماماً.
- لن يعمل الجهاز في حالة تركيب المطحنة بشكل غير صحيح.
- لا تستخدمي مكونات ساخنة لمعالجتها في المطحنة، اتركيها لتبرد في درجة حرارة الغرفة قبل معالجتها.

المفرمة / المطحنة الصغيرة

- لا ينصح بمعالجة التوابل، فقد تسبب في تلف الأجزاء البلاستيكية.

مطحنة الفرم

- لا تحضري جذور الكركم الجافة بواسطة المطحنة حيث أنها صلبة جداً وقد تتلف الشفرات.

مستخلص العصير

- لا تستخدمي العصارة إذا كانت المصفاة أو الغطاء العلوي للعصارة أو السلطانية تالفة أو بها شقوق واضحة.
- شفرات القطع على قاعدة اسطوانة المصفاة حادة جداً، توخي الحذر عند التعامل مع الاسطوانة وتنظيفها.
- استخدمي عصا دفع الطعام المرفقة فقط. يحظر وضع أصابعك في أنبوب التغذية. افصلي الجهاز قبل فك أنبوب التغذية.
- قبل إزالة الغطاء العلوي، أوقفي تشغيل الجهاز وانتظري إلى أن يتوقف المصفاة.

ملحق Express Dice/Express Serve والأقراس

- شبكة التقطيع والأقراس حادة للغاية؛ تعامل معها بحذر عند التركيب والإزالة والتنظيف. أمسكي الجهاز دائمًا من خلال المقبض بعيدًا عن حافة التقطيع عند التعامل مع شفرات التقطيع الحادة، وعند تفريغ الوعاء وأثناء التنظيف.

- يحظر استخدام أصابعك لدفع الطعام إلى أسفل أنبوب التغذية. استخدمي عصا دفع المكونات المرفقة فقط.
- يحظر استخدام القوة المفرطة لدفع الطعام إلى أسفل أنبوب التغذية - فقد يؤدي ذلك إلى تلف الملحق.
- قبل إزالة الغطاء العلوي، أوقفي تشغيل الجهاز وانتظري إلى أن يتوقف الفرس تمامًا.
- لا تصبِي السوائل الساخنة إلى أسفل خلال أنبوب التغذية.

- لا تستخدمي الزجاجة إلا مع مجموعة الشفرات الميرفقة.
- يحذر شرب أي سوائل ساخنة من الزجاجة.
- عند تناول الشراب عبر الغطاء العلوي، توخي الحذر حيث يكون الشراب مصحوباً برغوة.
- قد تكون بعض التجارب ضرورية للوصول إلى النتيجة المرجوة لا سيما عند تجهيز أطعمة صلبة أو غير كاملة النضج حيث قد تجدين بعض من المكونات لا تزال غير مجهزة.
- لا تمزجي المكونات المجمدة أو مكعبات الثلج بدون إضافة سائل.
- يحذر مزج المكونات الجافة (على سبيل المثال، التوابل والمكسرات) كما يحذر تشغيل مازج المشروبات فارغاً.

المازج المصنوع من الزجاج الحراري فقط مهم: تعليمات مزج المكونات الساخنة

لتقليل احتمالية الحروق عند مزج المكونات الساخنة، أبقي اليدين والجلد المكشوف الآخر بعيداً عن الغطاء العلوي لمنع الحروق المحتملة.

يجب مراعاة الاحتياطات التالية:

- تحذير: قد يؤدي مزج المكونات شديدة السخونة إلى اندفاع السائل الساخن والبخار فجأة من الغطاء العلوي وغطاء التعبئة.
- ينصح بترك المكونات الساخنة حتى تبرد قبل قلب المزج.
- يحظر تجاوز علامة السائل الساخن على الدورق إذا كنت تحضرين مكونات ساخنة، مثل الحساء.
- ابدئي دائمًا المزج بسرعة منخفضة وقومي بزيادة السرعة تدريجياً. يحظر مزج السوائل الساخنة باستخدام إعداد التشغيل "النبضي".
- يجب أن يكون حد السعة القصوى المستخدمة للسوائل التي تميل إلى إنتاج رغوة مثل الطليب هو ١٠٠٠ مل/٤ أكواب.
- توخي الحذر عند التعامل مع المازج حيث أن الدورق ومحتوياته سيكونون ساخنين للغاية.
- توخي الحذر بشكل خاص عند إزالة الغطاء العلوي. تم تصميم الغطاء العلوي بحيث يكون محكمًا للغاية لمنع التسرب. إذا لزم الأمر، احمي يديك بقطعة قماش أو ففازات فرن عند التعامل.
- تأكدي من توصيل ربط الدورق بشكل محكم بالقاعدة وعند إزالته من الجهاز، وجهي القاعدة وتتأكدي من إزالتها مع الدورق.
- تأكدي من أن الغطاء العلوي وغطاء التعبئة مثبتين في موضعهما بشكل محكم قبل كل عملية مزج.
- تأكدي دائمًا من أن الفتحات الموجودة في غطاء التعبئة نظيفة قبل كل عملية مزج.
- عند تركيب الغطاء العلوي على الدورق، تأكدي دائمًا من نظافة حافة الغطاء العلوي والدورق وجفافها لضمان الإغلاق المحكم ومنع الانسكاب.

- تحذير: قبل إزالة الغطاء العلوي عن السلطانية أو المازج أو المطحنة الاستخدامات عن وحدة الطاقة (المotor):
 - أوقفي تشغيل الجهاز;
 - انتظر حتى توقف الملحقات/الشفرات تماماً عن الحركة;
 - يحظر قك الدورق/zجاجة أو وعاء الطحن/gطاء العلوي من مجموعة الشفرات.
- لا تستخدمي الغطاء العلوي لتشغيل جهاز تحضير الطعام، استخدمي دائمأ زر تحكم السرعة On/Off (تشغيل/إيقاف).
- **سيتلف الجهاز وقد تحدث إصابات في حالة تعرض آلية التعشيق لقوة مفرطة.**
- يحذر استخدام أي ملحقات غير معتمدة.
- يحذر استخدام الجهاز في حالة تلفه. في مثل هذه الحالة، يجب فحص الجهاز أو إصلاحه: راجعي قسم «الصيانة ورعاية العملاء».
- يحذر تعرض وحدة الطاقة أو السلك الكهربائي أو قابس التوصيل للماء.
- لا تسمحي بتدلي السلك الكهربائي الزائد عن طاولة العمل ولا تسمحي له أيضاً بالالتلامس مع أسطح ساخنة.
- يجب الإشراف على الأطفال للتأكد من عدم عبئهم بالجهاز.
- لا يجوز استخدام هذا الجهاز من قبل الأطفال. احتفظي بالجهاز والسلك الكهربائي بعيداً عن متناول الأطفال.
- يمكن استخدام الأجهزة من قبل أشخاص ذوي قدرات جسدية أو حسية أو عقلية منخفضة وممن هم دون خبرة أو معرفة باستخدام الأجهزة في حالة منحهم التعليمات الخاصة بالاستخدام أو الإشراف عليهم بحيث يمكنهم استخدامه بطريقة آمنة مع إدراك المخاطر التي تتطوى على استخدام الجهاز.
- استخدمي الجهاز فقط في الاستخدامات المنزلية المخصص لها. لن تتحمل شركة Kenwood أية مسؤولية في حالة استخدام الجهاز بطريقة غير صحيحة أو عدم الامتثال للتعليمات المذكورة.
- قد يؤدي سوء استخدام جهاز تحضير الطعام أو المازج أو المطحنة إلى حدوث إصابات.
- تعتمد السعة القصوى على ملحق القطاعه/mطحنة الصغيرة المستخدم الذي يستمد حملأ أكبر. بعض الملحقات الأخرى قد تستمد حملأ أقل.

المازج/Blend-Xtract 2GO

- لا تستخدمي مكونات ساخنة أثناء التحضير.
- مخاطر التعرض لحرائق: يجب ترك المكونات الساخنة حتى تبرد وتصبح في درجة حرارة الغرفة قبل إضافتها إلى دورق/zجاجة المازج قبل المزج.
- توخي الحذر دائماً عند التعامل مع وحدة الشفرات وتجنبى لمس حافة القطع الخاصة بالشفرات أثناء التنظيف.
- يجب تشغيل المازج فقط مع تركيب الغطاء العلوي في موضعه.
- يحذر تشغيل المازج فارغاً.
- بالنسبة لوصفات المشروبات ذات الرغوة - يحظر مزج المكونات المجمدة التي تحولت إلى كتل صلبة أثناء التجميد، ولكن هشميها إلى أجزاء قبل إضافتها إلى الدورق/zجاجة.

عربي

قبل قراءة التعليمات الرجاء، فتح الصفحة الامامية التي تحتوى على الرسومات التوضيحية.

لسلامتك

- اقرئي التعليمات التالية واحتفظي بها في المتناول للاستخدامات المستقبلية المرجعية.
- أزيلي مكونات التغليف وأية ملصقات.
- لأسباب متعلقة بالسلامة ولتجنب حدوث أية مخاطر، في حالة تلف السلك الكهربى أو القابس، يجب استبداله بواسطة Kenwood أو مركز خدمة معتمد من قبل Kenwood.
- لا تلمسي الشفرات الحادة. لشفرات وأسطح القطع حادة، يجب التعامل معها بمنتهى الحذر. امسكى الجهاز من خلال المقبض الموجود في الأعلى، بعيداً عن حافة التقطيع، عند التعامل مع شفرات التقطيع الحادة، وعند تفريغ الوعاء وأثناء التنظيف.
- لا تستخدمي مكونات ساخنة أثناء التحضير.
- توخي الحذر في حالة سكب السائل الساخن في جهاز تحضير الطعام أو المازج فقد يتم إخراجه من الجهاز بسبب التبخير المفاجئ.
- لا تركي الجهاز دون ملاحظة أثناء تشغيله.
- لا تتجاوزي السعات القصوى الموصى بها والمحددة في جدول الاستخدام.
- لا تستخدمي الجهاز لأ زمنة أطول من تلك الموضحة أدناه دون السماح بفترات الراحة. استمرارية معالجة المزيد من المكونات لفترة زمنية أطول قد يتسبب في تلف الجهاز.

| فترات الراحة بين مرات التشغيل | الحد الأقصى لزمن التشغيل | الوظيفة/الملحق |
|---|--------------------------|--|
| افصلي الجهاز عن مصدر التيار الكهربى واترآيه ليبرد لمدة ١٥ دقيقة | ٦٠ ثانية | المازج Blender/Blend Xtract 2GO- |
| | ٦٠ ثانية | خلطات ثقيلة في السلطانية (على سبيل المثال، العجين) |
| | ٣٠ ثانية | المفرمة / المطحنة الصغيرة |
| | ٦٠ ثانية | مطحنة الفرم |

- لا تقومي برفع أو حمل جهاز تحضير الطعام من المقبض - حيث قد ينكسر المقبض مما يتخرج عنه حدوث إصابات.
- أزيلي سكين التقطيع دائمًا قبل صب المحتويات من السلطانية.
- أبقى على يديك وأدوات المطبخ خارج السلطانية ودورق المازج أثناء التوصيل مع مصدر التيار الكهربى. إذا كان من اللازم دفع الطعام إلى أسفل استخدمي أداة مناسبة مثل الملعقة البلاستيكية.
- قومي دائمًا بإيقاف تشغيل الجهاز وفصله من مصدر التيار الكهربائي إذا ترك دون مراقبة، وقبل التجميع أو التفكك أو التنظيف.
- لا تستخدمي أصبعك لدفع الطعام خلال أنبوب التغذية. استخدمي دائمًا عصا دفع المكونات المزودة.
- تحظر تركيب محموعة الشفرات في وحدة الطاقة (المotor) بدون تركيب الدورق/الرجاجة أو وعاء الطحن/الغطاء العلوي.

made in China

Kenwood Ltd

New Lane
Havant
Hampshire
PO9 2NH

kenwoodworld.com

© Copyright 2021 Kenwood Limited. All rights reserved



143912/2